



How to get Page Counts

Lexmark 460DN, 463DE, XS654DE, 654DN, XS658DE, 736DE

Select "Menu" then Scroll down and select "Reports", press the "check" button, scroll down and select "Device Statistics", and select the check button once again. Applies to the following Lexmark Devices; Lexmark 460DN, 463DE, XS654DE, 654DN, XS658DE, 736DE

The Lexmark 260DN is a basic printer without an advance menu system. To get the page counts from this device do the following; Hold the "Green Right Arrow" button and the "Red X" button at the same time for 10 seconds.

Toshiba 350p Right Arrow, then utilities menu, select "check" then select "print stats".

HP 5P, 6P, 2100, and 2200

Press the two buttons at the same time. A configuration page will print.

HP HP LaserJet 1100

Depress both buttons simultaneously.

HP LaserJet 1200

Depress green power button.

HP LaserJet 1300

Depress green power button for 5-6 seconds until it flashes amber (less than 5 seconds will only provide print sample. NOT a configuration page).

HP 1600C

Press the large blue button for the test page

HP 4000N, 4000TN

Press the MENU button until INFO MENU appears on the display. Press the ITEM button until PRINT EVENT LOG appears on the display. Press the SELECT button to print the test page.

HP 4000, 4050, 8000, 8100, 4500, 4550, 8500, and 8550

Press the right side of the MENU button until INFORMATION MENU appears on the display. Press the ITEM button until CONFIGURATION PAGE appears on the display. Press the SELECT button. A configuration page will print.

HP 4101 MFP

Press MENU button. Scroll to INFORMATION, enter (check button). Scroll to PRINT CONFIG, enter (3 pages)

New HP (post 4100) and MFP's

Scroll to INFORMATION, enter (check button). Scroll to CONFIG, enter

HP 8500DN

Press the MENU button until INFORMATION MENU appears on the display. Press the ITEM button until PRINT CONFIGURATION PAGE appears on the display. Press the SELECT button to print the test page.

HP 9000

Press the button with the check mark to enter the menus. Press the up arrow until INFORMATION MENU appears on the display. Press the button with the check mark. Press the up arrow until CONFIGURATION PAGE appears on the display. Press the button with the check mark. A configuration page will print.

New HP MFP InkJets (>2002)

Menu or Tools button to INFORMATION, enter. Arrow scroll to CONFIG or REPORTS, scroll to CONFIG or USAGE REPORT, enter.

